


QUICK START GUIDE

Must Read

1



Use 110V AC and plug into a grounded outlet.

2




Let the unit stand upright for 30 minutes after transport.

3



Keep air inlets and outlets clear of obstructions.

4



Remote requires 2 × AAA batteries (Not Included).

Power Requirements

Long press the Power button to turn on/off the AC unit.



Standard Household Outlets:

- Standard 110V AC power
- Three-prong outlet



Campsite Power Hookups:

- Standard 110V AC power
- 4A max. input current



Portable Power Stations:

- 110V AC output
- Minimum 400W power (Surge 1600W)



Solar Power Kit with Generator & Power Station:

- 110V AC output
- Minimum 400W power (Surge 1600W)

For off-grid use, choose a portable power station with at least 400 W continuous output and 1600 W surge capacity for optimal performance.

Tips

- No worries if the portable air conditioner is transported upside down—just place it upright and wait 24–48 hours before plugging it in.
- The flammable symbol is required by safety regulations. The portable air conditioner is safe to operate under normal conditions—simply keep it away from open flames or sparks.

2

YEARS

WARRANTY

We may not be superheroes for life—but we can be your HERO for this portable AC unit. Just reach out anytime.

✉ support@waykar.com ☎ (213)-895-4871



Quick Setup: Placed inside a Tent

1




Locate the **top warm air outlet**. Hold down the spring latch on the connector. Position it over the outlet and push firmly until seated. Let go of the latch to secure the connection.

2



Align the matching exhaust hose with the duct connector, then rotate it counterclockwise until it is securely attached.

3



Place the AC unit **inside** a tent. Extend the exhaust hose and direct it **outside** the tent through a suitable opening or flap.

Quick Setup: Placed outside a Tent

1



Locate the **side cool air outlet**. Hold down the spring latch on the connector. Position it over the outlet and push firmly until seated. Let go of the latch to secure the connection.

2




Align the matching exhaust hose with the duct connector, then rotate it counterclockwise until it is securely attached.

3



Place the AC unit **outside** a tent. Extend the exhaust hose and direct it **into** the tent through a suitable opening or flap.

Control Panel Illustration



Note: Press and hold the  button for 3 seconds to turn on the AC unit.

Indicator Explanation

Symbol	Meaning	Symbol	Meaning
	Cool Mode		Dry Mode
	Sleep Mode		Fan Mode
	Low Fan Speed		High Fan Speed
	Full Water Signal		Timer Symbol